

## Adhesive recommendation

### allure „LWT Wall tile“

The wall surfaces must be dry, sufficiently even and free from any separating agents	
1. Subsurface preparation	<b>Remove wallpapers and paints, grind or brush the surface</b> In case of appropriate evenness, proceed from point 4 In case of unevenness proceed from point 2 and 3
2. Primer	<b>BOSTIK TIEFENGRUND</b> approx. 200 – 400 gm per m <sup>2</sup>
3. Filler / levelling compounds	<b>NIBOPLAN W 26 or NIBOPLAN W 28</b> approx. 1,0 kg per m <sup>2</sup>

Wall surfaces in living areas	
4. Adhesive	<b>BOSTIK`S BEST</b> Notched trowel TKB A 2 or a large-pored moltoprene roller (yellow) approx. 300 gm per m <sup>2</sup>
5. Wall tile	wall tile

Wall surfaces in moisture or wetrooms*	
4. Adhesive	<b>ARDAFLEX MULTI</b> Notched trowel TKB A 2 or a large-pored moltoprene roller (yellow) approx. 300 gm per m <sup>2</sup>
5. Wall tile	wall tile

\* please notice the BEB leaflet „Abdichtungsstoffe im Verbund mit Bodenbelägen“ wet duty classes AO, BO (medium load)

All stated adhesives are audited to the GEV „Gemeinschaft emissionskontrollierter Verlegewerkstoffe“ and meet the requirements of „EC1“ or „EC1 Plus“. In addition some products meet the requirements of RAL UZ 113. In case of any further questions, do not hesitate to contact Bostik´s technical department.

**Please observe the technical data sheets of the above mentioned products as well as the wall tile producers installation instructions.**

Stand März / 2016